

Case Study:

Modeling IBIS for Open_drain True Differential Pair Buffer

Lance Wang, IO Methodology Inc.

Yan Liang, Maxim Integrated


Asian IBIS Summit – Shanghai, China November 11th, 2016



Outline

- Open_drain Differential Pair Buffer Structure
- Review IBIS Modeling Method
 - Differential Pair Modeling Method
 - Output Type Buffer
 - Open_drain Type Buffer
- Practical Method for Open_drain Differential Pair Buffer
- Conclusions

Open_drain Differential Pair Buffer Structure




Review IBIS Modeling Method


- Differential Pair Modeling Method
- Output Type Buffer
- Open_drain Type Buffer

Differential Pair Modeling Method

- IBIS uses two single-end models to be a differential pair
- IBIS uses [Diff Pin] to define two pins to be a differential pair pins
- Uses two opposite inputs as required




Output Type Buffer (non-inverting)



Set Input LOW to extract Pullup curve

Set Input HIGH to extract Pulldown curve

Open_drain Type Buffer




Set Input HIGH to extract Pulldown curve

Set Input LOW to extract PowerClamp curve

Set Input LOW to extract GroundClamp curve


Practical Method for Open_drain Differential Pair Buffer

- As the normal method, we will use two Open_drain type IBIS models for Positive and Negative pins.





Let's validate

The Topology for Validation



Validation Results




Root cause for mismatch and solution



- We missed some currents in the IBIS models
 - There is some current between P and N pins
 - IBIS Open_drain type model without Pullup curve.
Assuming Pullup current is Zero
- Solution
 - We can use Output type model to capture all curve data
 - However, we need to use Open_drain type setting to capture the data

New solution validation result

IBIS



SPICE





Conclusion


- Open_drain differential pair is a special case for IBIS modeling
 - IBIS Open_drain model is without the Pullup data
 - We need to use Output/IO type IBIS model to capture the Pullup data for this kind of differential pair buffer
 - However we need to IBIS Open_drain modeling setting for extractions
- IBIS C_comp needs to improve to be matched better

C_comp

- Currently, IBIS Spec only allows 4 values at the most
- We might need to have more C_comp values according DC levels and frequency changes
- Study is in process ...



The Modeling Specialist



<http://www.iometh.com>